

Proper Carriage Bolt Application

Effective: Jan 1, 2011

- All loaded containers entering Union Pacific Intermodal Terminals must either have a high security bolt seal OR must have a carriage bolt properly applied by the drayage driver.

REQUIRES CARRIAGE BOLT



NO CARRIAGE BOLT REQ'D



HIGH SECURITY BOLTS



Proper Carriage Bolt Application

1.5" distance



Improper Carriage Bolt Application



BUILDING AMERICA®